


User Guide

Front bezel controls



23.8–inch and 27–inch models		
Component		**Function**
1	Camera microphones	Allow you to participate in a video conference.
2	Camera light	On: The camera is in use.
3	Camera lens	Transmits your image in a video conference.

USB/Side components



23.8–inch model		
Component		**Function**
1	USB ports (2)	Connect USB devices.

Turning on the monitor

1. Press the power button on the computer to turn it on.
2. Press the power button on the bottom of the monitor to turn it on.

